




USER GUIDE


Indy

Auto Power - On




- Power - On
- On
- Encendido
- Accensione
- Ligar
- Ein
- Aan-
- Tænd
- Virta Päälle
- Ström Av
- Ström Av
- Включить
- 开机
- 電源 - On
- 전원 켜기
- إشغال تشغيل

Auto Power - Off




- Power - Off
- Off
- Apagado
- Spegnimento
- Desligar
- Aus
- Uitzetting
- Sluk For Strøm
- Pois
- På
- På
- выключить Питание
- 关机
- 電源 - Off
- 끄기
- إشغال

Charge Case




- Charge Case
- Rechargez L'étui
- Estuche De Carga
- Carica La Custodia
- Estojo De Carregamento
- Hülle Aufladen
- Opladetui
- Opladeretui
- Lataa Kotelo
- Ladingseske
- Laddningsfodral
- Чехол-аккумулятор
- 充電座
- 充電ケース
- 케이스를 충전하세요
- حاجز شحن

Charge Earbuds



- Charge Earbuds
- Rechargez Les Écouteurs
- Audifonos De Carga
- Carica Gli Auricolari
- Carregar Auriculares
- Kopfhörer Aufladen
- Opladen Oordoppen
- Oplad Høretelefoner
- Lataa Nappikuulokkeet
- Lade Örepluggar
- Ladda Öronsnäckor
- Наушники С Аккумулятором
- 为耳机充电
- イヤホン充電
- 이어버드를 충전하세요
- شحن سماعات

Pairing Mode




- Pairing Mode
- Mode Couplage
- Modo De Vinculación
- Modalità Di Accoppiamento
- Modo Emparelhamento
- Koppelmodus
- Paarmodus
- Pardanneelsevstiland
- Laiteparin Muodostusta
- Sammenkoblingsmodus
- Parningsläge
- Режим Сопрежения
- 配对模式
- ペアリングモード
- 페어링 모드
- وضع الاقتران

Pair New Device "Indy"




- Pair New Device
- Coupler Nouvel Appareil
- Vincular Nuevo Dispositivo
- Accoppia Nuovo Dispositivo
- Emparelhar Novo Dispositivo
- Mit Neuem Gerät Koppeln
- Nieuw Apparaat Paren
- Pardan Ny Enhet
- Muodosta Uusi Laiteparin
- Sammenkoble Ny Enhet
- Para Ny Enhet
- Сопрежение Нового Устройства
- 配对新设备
- 新しいデバイスをペアリング
- 새 기기 짝 맞추기
- شحن جهاز جديد

Power - On




- Power - On
- On/off
- Encendido
- Accensione
- Ligar
- Ein
- Aan-
- Tænd
- Virta Päälle
- Ström Av
- Ström Av
- Включить
- 开机
- 電源 - On
- 전원 켜기
- إشغال

Power - Off




- Power - Off
- Off
- Apagado
- Spegnimento
- Desligar
- Aus
- Uitzetting
- Sluk For Strøm
- Pois
- På
- På
- выключить Питание
- 关机
- 電源 - Off
- 끄기
- إشغال

Play/Pause



- Play/pause
- Lecture/pause
- Reproducir/pausar
- Riproduci/pausa
- Reproduzir/colocar Em Pausa
- Wiedergabe/pause
- Afspelen/pauzeren
- Afspil/pause
- Toisto/tauko
- Spill/pause
- Spela Upp/pausa
- Воспроизведение/пауза
- 播放/暫停
- 再生 / 一時停止
- 재생/일시 정지
- شحن مؤقت/إيقاف

Track Forward




- Track Forward
- Piste Suivante
- Adelantar
- Brano Successivo
- Faixa Seguinte
- Nächster Titel
- Vorgend Nummer
- Skift Til Næste Musiknummer
- Kelaus Eteenpäin
- Neste Spor
- Nästa Ljudspår
- Переключение На 1 Трек Вперед
- 下一曲目
- 次のトラックを再生する
- 다음 트랙으로
- مسار التالي

Track Back




- Track Back
- Piste Précédente
- Retroceder
- Brano Precedente
- Faixa Anterior
- Vorangehender Titel
- Vorig Nummer
- Musiknummer Tilbage
- Kelaus Taaksepäin
- Fornige Spor
- Byta Till Föregående Spår
- Переключение На 1 Трек Назад
- 上一曲目
- 前のトラックを再生する
- 이전 트랙으로
- شحن السابق

Volume Up




- Volume Up
- Volume +
- Subir Volumen
- Aumento Volume
- Aumentar O Volume
- Lautstärke Erhöhen
- Volume Omhoog
- Skru Op For Lydstyrken
- Äänenvoimakkuuden Lisäys
- Volym Opp
- Öka Volymen
- Увеличение Громкости
- 音量增大
- 音량을上げる
- 볼륨 높이기
- رفع مستوى الصوت

Volume Down




- Volume Down
- Volume -
- Bajar Volumen
- Riduzione Volume
- Diminuir O Volume
- Lautstärke Senken
- Volume Omaag
- Skru Ned For Lydstyrken
- Äänenvoimakkuuden Vähennys
- Volym Ned
- Sänka Volymen
- Уменьшение Громкости
- 音量减小
- 音량을lower
- 볼륨 낮추기
- خفض مستوى الصوت

Answer/End




- Answer/end
- Répondre/fin
- Responder/colgar
- Risposta/line
- Atender/desligar
- Annehmen/beenden
- Beantwoorden/beëindigen
- Besvar/afslut
- Vastaus/lopetus
- Svar/avslutt
- Svara/lägg På
- Ответить/закончить
- 接听/結束
- 応答 / 終了
- 전화 받기/끊기
- عامة الرد

Activate Voice Assistant



- Activate Voice Assistant
- Activer l'assistant vocal
- Activar el asistente de voz
- Attivare assistente vocale
- Ativar assistente de voz
- Sprachassistenten aktivieren
- Sternhulp activeren
- Aktivér talestøtte
- Aktivoi ääniohjain
- Aktiver taleassistent
- Aktivera röstassistent
- Активировать голосовой помощник
- 激活语音助理
- ボイスアシスタントを
- アクティベートする
- 음성 인식 가동화
- شحن وصلة مع اسم المساعد الصوتي

Clear Paired Device



- Reset Device
- Réinitialiser l'Appareil
- Reiniciar el Dispositivo
- Ripristina Dispositivo
- Reinicie o Dispositivo
- Rückstelleneinrichtung
- Reset het Apparaat
- Nustil Enhet
- Nollaa Laite
- Nustil Enhet
- Återställ Enhet
- Сброс устройства
- 重置设备
- デバイスをリセット
- 기기 재설정
- إعادة ضبط الجهاز

Questions Visit: www.skullcandy.com
 Si vous avez des questions, allez sur : www.skullcandy.com
 Si tienes dudas, visita: www.skullcandy.com
 Domande Visitate il sito: www.skullcandy.com
 Fazer perguntas: www.skullcandy.com
 Fragen Besuch: www.skullcandy.com
 Voor vragen bezook: www.skullcandy.com
 For spørsmål se: www.skullcandy.com
 Vastauksia löytyy: www.skullcandy.com
 For spørsmål, besök: www.skullcandy.com
 Vid frågor, besök: www.skullcandy.com
 Если у вас возникнут вопросы, посетите: www.skullcandy.com
 如有疑问请访问: www.skullcandy.com
 質問がある場合はこちらをご覧ください: www.skullcandy.com
 문의 사항: www.skullcandy.com
www.skullcandy.com / www.skullcandy.com / www.skullcandy.com

EN Speaker Driver: 6mm, Impedance: 16 Ohms, THD <3%@1KHz, Voltage Regulation: 5V, 500mA, Bluetooth® 5.0, Frequency Band: 2402MHz - 2480MHz, Maximum Power: <9dBm, Weight: 59.5g, FR Driver President: 6mm, Impedance: 16 Ohms, THD <3%@1KHz, Tension: 5V, 500mA, Bluetooth® 5.0, Bande de fréquence: 2402MHz - 2480MHz, Puissance Maximum: <9dBm, Poids: 59.5g, ES Controlador del altavoz: 6mm, Impedancia: 16 Ohms, THD <3%@1KHz, Voltaje: 5V, 500mA, Bluetooth® 5.0, Banda de frecuencia: 2402MHz - 2480MHz, Potencia Máxima: <9dBm, Pesa: 59.5g, DE Lautsprecher-Treiber: 6mm, Impedanz: 16 Ohm, THD <3%@1KHz, Spannungsregelung: 5V, 500mA, Bluetooth® 5.0, Frequenzband: 2402MHz - 2480MHz, Maximale Performance: <9dBm, Gewicht: 59.5g, JP スピーカードライバ: 6ミリメートル, インピーダンス: 16オーム, THD <3%@1KHzの, 電圧レギュレーション: 5Vの, 500mA, Bluetooth® 5.0, 周波数帯域: 2402MHz - 2480MHz, 最大パフォーマン: <9dBm, 重量: 59.5グラム, ZH 扬声器驱动器: 6毫米, 阻抗: 16欧姆, THD <3%@1KHz, 电压调节: 5V, 500mA, 蓝牙: 2402MHz - 2480MHz, 最大功率: <9dBm, 重量: 59.5克.

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED Compliance Statement
 This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference.(2)This device must accept any interference, including interference that may cause undesired operation of the device.

ISED SAR Compliance Statement
 This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The portable device is designed to meet the requirements for exposure to radio waves established by the ISED. These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body. Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. L'utilisateur final doit suivre les instructions spécifiques pour satisfaire les normes. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur. Le dispositif portatif est conçu pour répondre aux exigences d'exposition aux ondes radio établie par le développement énergétique DURABLE. Ces exigences un SAR limite de 1,6 W/kg en moyenne pour un gramme de tissu. La valeur SAR la plus élevée signalée en vertu de cette norme lors de la certification de produit à utiliser lorsqu'il est correctement porté sur le corps.

Americas
 Skullcandy, Inc.
 6301 N Landmark Dr.
 Park City, UT 84098 U.S.A.
Skullcandy.com

Europe
 Skullcandy Europe BV
 Postbus 425
 6500AK Veldhoven Nederland
Skullcandy.eu

México
 Skullcandy Mexico S de RL de CV
 Aristoteles 218
 Polanco IV Seccion, Miguel Hidalgo
 11550, México City, México
Skullcandy.mx

Canada
 Skullcandy Canada ULC
 329 Railway St, Unit 205
 Vancouver, BC, V6A 1A4 Canada
Skullcandy.ca

Japan/日本
 Skullcandy Japan合同会社
 〒150-0001 東京都渋谷区神宮前
 5-17-11 パークサイドオーチャード2階
 Skullcandy Japanカスタマーサービス
 商品についてのお問い合わせはこちら
Skullcandy.jp

EN Contains Li-ion battery. Battery must be recycled or disposed of properly.
 FR Contient une batterie Li-ion. La batterie doit être recyclée ou jeté s correctement.
 ES Contiene una batería Li-ion. La batería debe ser reciclada o desechada adecuadamente.
 Hardware Version: V1.3
 Software Version: V6.0

EN Made in China.
 FR Fabriqué en China.
 ES Hecho en China.
 ZH 中国制造
MODEL: S2SSW
FCC ID: Y22-S2SSW
IC: 10488A-S2SSW

